



KEY STORAGE SECURITY LOCK

Thieves know the usual hiding places

WARNING

You MUST lock onto a hidden place on a vehicle. Thieves with the right tools can break into any lock. The maker, distributor, or seller, gives no warranty that this Key Storage Lock is thief proof

- The **SEACURED** security lock is perfect for when you can't take your keys with you, or, you have several people that need access to your keys
- Attaching to vehicle suggestions; Vehicle tie down points, Suspension coil springs,

- **RESETTING COMBINATION INSTRUCTIONS**

- **Please read all instructions thoroughly before resetting combination**

- Your **SEACURED** security lock is pre-set to 0-0-0-0 from the factory.
- The lock must be on the code to be able to change it.
- Go to the reset pin, located on the inside of the box. Pull the rubber plug off the pin, slide the reset pin to the right and up position as shown on fig.1
- Select the new combination (Write down or store in your mob. phone the new combination for future reference)
- Slide the reset pin back down and to the left **before closing**.
- Replace the rubber plug
- Check the operation of the lock using the new combination.



- **INSTRUCTIONS FOR USE**

Key storage: Dial in correct combination. (Default is 0-0-0-0) Place one hand on the shackle, with your other hand grab the sides of the **SEACURED** security lock and pull the front open like you would an oven door.

Shackle: Move and hold the silver lever to the right while pulling on the shackle (The lever is located inside the box at the top near the shackle)



For Keyless (FOB) Ignition vehicles (Not guaranteed to work on all keyless vehicles) Use the keyless FOB/Remote to lock the car (do not use the button on the car door handle). Place keyless FOB inside one of the alloy bags provided and fully zip up bag before putting inside the **SEACURED LUMIN LOCK**. Do not attach the lock to the door handle.

IMPORTANT- CHECK CAR IS LOCKED BEFORE LEAVING.

The dials have a feature of stopping on 0-0-0-0 by spinning the dials up towards the shackle. This is so you can feel the notches to get to your code if you can't see the dials.

- **LOCKING**

Insert keys into key storage area, close the key storage area and move the dials to an alternate setting.

We recommend you apply (once a month) a little lubricant spray into the hole where the shackle bolt goes as well as into the reset lever, the dials on the outside and the Hinge points. This will keep your lock in good working condition for many years to come.